


Where will it cut?

In **Landscape** mode, the bottom of the screen, is the left edge of the carrier sheet, so a word at the bottom of the screen like this



Will cut on the left side like this



If you open the Robo Master software up in **Portrait** mode, then the bottom of the page is the first piece that will be cut, ie the *top* of the carrier sheet. So, you almost have to think of the page as being upside down. the top of your paper goes into the Craft Robo LAST